

# MINI MIST WATER SENSOR CLEANING INSTRUCTIONS

**DO NOT DISCARD**

## a Long Life for Your **Steam-Whirl** Steambath...

CONGRATULATIONS ON YOUR PURCHASE OF ONE OF THE HEALTHIEST AND REFRESHING PRODUCTS AVAILABLE TODAY. FOR OVER TWENTY YEARS OUR COMPANY HAS MAINTAINED THE HIGHEST STANDARDS IN PRODUCT MANUFACTURING AND CUSTOMER SATISFACTION. AS PART OF THIS COMMITMENT WE ARE PROVIDING THE FOLLOWING SERVICE INSTRUCTION TO HELP PROTECT AGAINST THE WORSENING CONDITIONS IN OUR WATER SUPPLY.

### SERVICE INSTRUCTIONS:

- SHUT OFF MAIN ELECTRICAL BREAKER.
- OPEN JUNCTION BOX & WITH A VOLT METER, TEST THAT THERE IS NO VOLTAGE ON L-1 AND L-2.
- REMOVE BRASS SCREW & 2-1/2" X 3" COVER FROM PANEL ON TOP OF UNIT TO ACCESS TOP OF BRASS PROBE.
- DISCONNECT RED AND BLACK WIRES FROM TOP OF PROBE SENSOR.
- CAREFULLY UNSCREW BRASS WATER SENSOR.
- SAND OFF ANY CALCIUM BUILD-UP ON SENSOR TIPS.
- CAREFULLY SCREW BRASS WATER SENSOR BACK IN.
- REINSTALL RED AND BLACK WIRES TO TOP OF PROBE SENSOR
- REINSTALL COVER.
- TURN ON MAIN ELECTRICAL BREAKER.

THIS MAINTENANCE IS SUGGESTED FOR ANY SERVICE SPECIALIST. DEPENDING ON THE IRON CONTENT IN LOCAL WATER WILL DETERMINE THE FREQUENCY OF PROBE SERVICE. START OUT AT LEAST ONCE A MONTH AND IF PROBE IS CLEAN AND NOT COATED, THAN TRY EVERY TWO MONTHS ETC. MORE FREQUENT SERVICING OF PROBE MAY BE NEEDED IF UNIT IS IN AN EXTREMELY HARD WATER AREA OR WATER IS SUPPLIED BY A WELL. PLEASE CALL FOR ANY ASSISTANCE.

TO ORDER A REPLACEMENT SENSOR, SIMPLY FILL OUT AND MAIL THE ENCLOSED ORDER FORM OR CONTACT A STEAM-WHIRL SALES REPRESENTATIVE AT (800) 232-7832.

### BRASS WATER SENSOR ORDER FORM

NAME \_\_\_\_\_  
ADDRESS \_\_\_\_\_  
CITY \_\_\_\_\_ STATE \_\_\_\_\_ ZIP \_\_\_\_\_  
TELEPHONE ( ) \_\_\_\_\_

#99-2115 @ \$52.00 EACH X ( )  
SHIPPING @ \$ 6.00

AMOUNT: \_\_\_\_\_  
TOTAL: \_\_\_\_\_

**NO C.O.D.**

SEND TO:  
STEAM-WHIRL  
3775 W TECO AVE #5  
LAS VEGAS, NV 89118-6827