

COMMERCIAL WATER SENSOR INSTRUCTIONS

DO NOT DISCARD

a Long Life for Your Steam-Whirl STEAMBATH...

CONGRATULATIONS ON YOUR PURCHASE OF ONE OF THE HEALTHIEST AND REFRESHING PRODUCTS AVAILABLE TODAY. FOR OVER TWENTY YEARS OUR COMPANY HAS MAINTAINED THE HIGHEST STANDARDS IN PRODUCT MANUFACTURING AND CUSTOMER SATISFACTION. AS PART OF THIS COMMITMENT WE ARE PROVIDING THE FOLLOWING SERVICE INSTRUCTION TO HELP PROTECT AGAINST THE WORSENING CONDITIONS IN OUR WATER SUPPLY.

SERVICE INSTRUCTIONS:

- SHUT OFF MAIN ELECTRICAL BREAKER.
- OPEN DROPDOWN DOOR IN FRONT PANEL & WITH A VOLT METER, TEST THAT THERE IS NO VOLTAGE ON L-1 AND L-2.
- ON LEFT SIDE OF HEATER TANK, LOCATE THE WATER LEVEL SENSOR PROBE AND DISCONNECT RED AND BLACK WIRES FROM THE TOP.
- CAREFULLY UNSCREW COMMERCIAL WATER LEVEL SENSOR PROBE.
- SAND OFF ANY CALCIUM BUILD-UP OR DEBRIS ON SENSOR TIPS.
- **DO NOT CUT OR TRIM SENSOR WIRES.**
- APPLY WHITE TEFLON TAPE AROUND THREAD.
- CAREFULLY SCREW WATER LEVEL SENSOR PROBE BACK IN.
- RE-INSTALL RED AND BLACK WIRES TO TOP OF WATER LEVEL SENSOR PROBE.
- TURN ON MAIN ELECTRICAL BREAKER.



WATER LEVEL SENSOR PROBE

THIS MAINTENANCE IS SUGGESTED FOR ANY SERVICE SPECIALIST. DEPENDING ON THE IRON CONTENT IN LOCAL WATER WILL DETERMINE THE FREQUENCY OF PROBE SERVICE. START OUT AT LEAST ONCE A MONTH AND IF PROBE IS CLEAN AND NOT COATED, THEN TRY EVERY TWO MONTHS ETC. MORE FREQUENT SERVICING OF PROBE MAY BE NEEDED IF UNIT IS IN AN EXTREMELY HARD WATER AREA OR WATER IS SUPPLIED BY A WELL. PLEASE CALL FOR ANY ASSISTANCE.

TO ORDER A REPLACEMENT SENSOR, SIMPLY FILL OUT AND MAIL THE ENCLOSED ORDER FORM OR CONTACT A STEAM-WHIRL SALES REPRESENTATIVE AT (800) 232-7832.

COMMERCIAL WATER SENSOR ORDER FORM

NAME _____
ADDRESS _____
CITY _____ STATE _____ ZIP _____
TELEPHONE () _____

#99-2110 @ \$65.45 EACH X ()
SHIPPING @ \$ 6.00

AMOUNT: _____
TOTAL: _____

NO C.O.D.

SEND TO:

STEAM-WHIRL
3775 W TECO AVE #5
LAS VEGAS, NV 89118-6827